


# OBD Bluetooth

## Android Quick Start Guide



### 2 Plug OBD connector (DLC)

The DLC is usually found on the driver's side, under the dash.



—Can't find your DLC? Visit [dlc-locator.com](http://dlc-locator.com)

### 3 Turn ignition on

'Power' LED will turn ON, and the 'BT' LED will start flashing slowly.

—LEDs are off? Check vehicle for blown fuses.

### 6

LED will switch to a *fast* blink.



### Attention!

You must complete steps 7, 8, and 9 within **2 minutes**. If you need more time, press the button again.


### 1 Download & install



### 4 Open 'Settings' app, and tap 'Wireless & networks'



### 5 Make sure 'Bluetooth' is enabled, then tap 'Bluetooth settings'.



### 7 Tap 'Scan for devices',



### 8 Tap 'OBD - Pair with this device'

[instructions continue on reverse]

9 Tap 'Pair' in the 'Bluetooth pairing request' dialog. PASS KEY 1234

You **do not** need to confirm the passkey.

Once successfully paired, OBD will appear as 'Paired but not connected':


10 Launch the OBD app, and tap 'Connect'

Once the connection is established, the 'BT' LED will turn on solid. Tap 'Diagnostics' to start a scan.

11 Optional: download third party OBD apps


### Torque

Tap 'Settings', 'OBD2 Adapter Settings', 'Choose Bluetooth Device', 'OBLink MX'. Return to the Torque home screen.



### DashCommand

Tap 'ELM', then 'Connection'.



Thank you for your purchase!  
*please post your review on*

**amazon.com**<sup>®</sup>

**ebay**<sup>™</sup>